



CVM Series			
My screen lights up but I do not get a picture.			
This is typically the result of a loss of video to the monitor but may also be a fault in the monitor itself. Areas to look at include: Camera(s), Camera Cable(s), Monitor, Switcher			
	Single Camera System Troubleshooting	Yes	No
Step 1	Are there any signs of damage to the camera or camera cable?	Repair damage and retest	Go to step 2
Step 2	Check the connections between camera and camera cable and monitor and camera cable. Make sure they are all connected properly. Did this fix your problem?	Done	Go to step 3
Step 3	Contact your Intec Service Rep. They may ask you to return equipment for service.		
	Multi Camera System Troubleshooting	Yes	No
Step 1	Do any of the camera positions (with cameras connected) produce an image?	Go to step 2	Go to step 4
Step 2	Unplug one of the camera cables from a working position and move it to the position(s) that is not working. Does the non-working position(s) now show an image? Make sure you've selected the correct position via the switch.	Go to step 3	Got to step 7
Step 3	Place the camera cables back in their original position and move only a working camera to the position(s) that are not working. Do you get an image?	Contact your Intec Service Rep. They may ask you to return your camera for service.	Check the camera cable for damage. It may need replaced.
Step 4	Is there a separate Car Vision switcher in your system?	Go to step 5	Go to step 7
Step 5	Check your monitor to switcher cable. Make sure it is not damaged and connected properly. Did this correct your problem?	Done	Go to step 6
Step 6	Unplug one of the camera cables from the switcher and plug it directly in to the monitor pigtail. Do you get an image?	Contact your Intec Service Rep. They may ask you to return your switcher for service.	Go to step 7
Step 7	Contact your Intec service rep. They may ask you to return your monitor for service.		